



Part Number	ESM Order Ref.	Illus. No.	Description	Remarks
Body shell - 2 door saloon				
CHS101	RP116R	1	Leg - chassis - R/H	
CHS102	RP116L	-	Leg - chassis - L/H	
CHS103	RP101R	2	Tie-plate - R/H	
CHS104	RP101L	-	Tie-plate - L/H	
CHS105	RP119	3	Plate - top - front crossmember	
CHS106	RP120	4	Crossmember - front	
CHS107	RP114AR	5	Bracket - tie-bar - R/H	
CHS108	RP114AL	-	Bracket - tie-bar - L/H	
CHS109	RP121R	6	Wheel arch - front - R/H	
CHS110	RP121L	30	Wheel arch - front - L/H	
CHS111	RP122R	7	Flitch - R/H	
CHS112	RP122L	-	Flitch - L/H	
CHS113	RP122BR	8	Extension - flitch - R/H	
CHS114	RP122BL	-	Extension - flitch - L/H	
CHS115	RP156R	9	Tube and stud - bumper - R/H	
CHS116	RP156L	-	Tube and stud - bumper - L/H	
CHS117	RP123R	10	Pillar - hinge - R/H	
CHS118	RP123L	-	Pillar - hinge - L/H	
CHS119	RP179R	11	Panel - front - side - inner - R/H	
CHS120	RP179L	-	Panel - front - side - inner - L/H	
CHS150	RP157R	12	Bracket - flitch to wheel arch - R/H	
CHS151	RP157L	-	Bracket - flitch to wheel arch - L/H	
CHS122	CHS122	13	Box - battery	
CHS123	RP177	14	Crossmember - gearbox- mount	
CHS124	RP103	15	Crossmember - centre	
CHS125	RP105	16	Bracket - jacking	
CHS126	RP105A	17	Rubber - jacking bracket	
CHS140	RP109R	18	Plate - boxing - sill - R/H	
CHS141	RP109L	-	Plate - boxing - sill - L/H	
CHS142	RP111R	19	Finisher - sill - R/H	
CHS142SS	RP111AR	19	Finisher - sill - stainless - R/H	
CHS143	RP111L	-	Finisher - sill - L/H	
CHS143SS	RP111AL	-	Finisher - sill - stainless - L/H	
CHS144	RP110R	20	Kick-plate - R/H	
CHS145	RP110L	-	Kick-plate - L/H	
CHS136	RP127AR	22	Wing - inner - rear - R/H	
CHS137	RP127AL	-	Wing - inner - rear - L/H	
CHS138	RP106AR	23	Bracket - rear spring - front - R/H	See also CHS719
CHS139	RP106AL	-	Bracket - rear spring - front - L/H	See also CHS720
CHS719	RP106R	-	Spring hanger bracket (on plate) - R/H	
CHS720	RP106L	-	Spring hanger bracket (on plate) - L/H	
CHS730	RP133R	25	Panel - side repair - R/H	
CHS731	RP133L	-	Panel - side repair - L/H	
CHS152	CHS152SH	26	Crossmember - rear seat support	
CHS750	RP150	27	Boot-lid closing panel repair	
CHS726	RP148	28	Rear bootwell panel	
CHS756	RP153	29	Bracket - boot lock striker plate mounting	
CHS110	RP121L	30	Wheel arch - front - L/H	
CHS153	CHS153	31	Bracket - wiper motor mounting	
CHS748	RP159R	32/33	Flange - rear inner wing - R/H	
CHS749	RP159L	-	Flange - rear inner wing - L/H	
CHS723	RP127R	34	Rear inner wing repair - R/H	
CHS724	RP127L	-	Rear inner wing repair - L/H	
CHS732	RP108R	35	Sill - outer - R/H	
CHS733	RP108L	-	Sill - outer - L/H	
CHS746	RP107R	36	Sill member - R/H	
CHS747	RP107L	-	Sill member - L/H	
CHS754	RP164R	37	B' post repair - R/H	
CHS755	RP164L	-	B' post repair - L/H	
CHS761	RP137A	38	Plate - rear bump stop	