



Part Number	ESM Order Ref.	Illus. No.	Description	Remarks
Bonnet panel and fittings - all models				
PAN139	RP160	1	Bonnet	
BPF101	BPF101SH	2	Bracket - lock - upper	
BPF102	BPF102SH	3	Crossmember	
LOG1003	LOG1003	4	Bonnet side badge - 'Minor 1000'	
LOG1004	SV125	-	Bonnet side badge - 'Morris Minor'	
FAS1001	FAS1001	-	Fixing clip for LOG1003/4	
BPF103	BPF103SH	5	Strip - anti-drum	
BPF104	BPF104SH	6	Rod - stiffener - R/H	
BPF105	BPF105SH	-	Rod - stiffener - L/H	
BPF106	BPF106SH	7	Prop - bonnet	
BPF107	BPF107	8	Spring - bonnet prop	
BPF108	BPF108SH	9	Pin - assembly - striker	
BPF109	BPF109SH	10	Bracket - lock - upper	
BPF110	BPF110	11	Pin	
BPF111	BPF111	12	Spring - bonnet prop	
BPF112	BPF112	13	Cup	
BPF113	BPF113	14	Plate - slider guide	
BPF114	BPF114SH	15	Slider	
BPF115	BPF115SH	16	Support - slide - lock	
BPF116	BPF116SH	17	Tube - distance - slider	
BPF117	BPF117	18	Spring - slider - tension	
BPF118	BPF118SH	19	Sleeve - slider tension spring	
BPF119	BPF119	20	Catch - safety	
BPF120	BPF120SH	21	Pin - safety catch	
BPF121	BPF121	22	Spring - safety catch	
BPF122	BPF122SH	23	Rod - lever to slider	
BPF123	BPF123SH	24	Lever	
BPF124	BPF124	25	Pin - lever pivot	
BPF125	BPF125SH	26	Rod - lock control	
BPF126	BPF126	27	Spring - anti-rattle	
BPF127	BPF127	28	Motif	
BPF128	BPF128	29	Motif	
BPF129	BPF129	30	Flash	
BPF130	BPF130	31	Flash	
BPF131	Use BPF131/2	32	Hinge - R/H	
BPF132	BPF132	-	Hinge - L/H	
BPF131/2	BPF131/2	-	Hinge - pair	
BPF133	BPF133	33/34	Bonnet hinge gasket (two part)	
BPF135	BPF135	35	Buffer - bonnet	
BPF136	BPF136	36	Buffer - dash	