



Part Number	ESM Order Ref.	Illus. No.	Description	Remarks
9M122	9M122	1	Rod - connecting - Nos. 1 & 3 cylinders	
9M123	9M123	2	Rod - connecting - Nos. 2 & 4 cylinders	
9M124	10M126	3	Screw - connecting rod	
9M125	10M127	4	Washer - lock	
9M126	9M126	5	Screw - clamp - gudgeon pin	
9M127	FIX157	7	Washer - spring - 5/16"	
			Bearing - 'big end'	
9M128/S	10M128/S	8	Standard	
9M128/10	10M128/10	8	.010" (0.254 mm) U/S	
9M128/20	10M128/20	8	.020" (0.508 mm) U/S	
9M128/30	10M128/30	8	.030" (0.762 mm) U/S	
9M128/40	10M128/40	8	.040" (1.016 mm) U/S	
9M129R	9M129	9	Crankshaft - with thrust washers and bearings	
9M130	10M130SH	10	Restrictor - oil	
9M131	10M131	11	Bush - 1st motion shaft	
			Bearing - main	
9M132/S	9M132/S	12	Standard	
9M132/10	9M132/10	12	.010" (0.254 mm) U/S	
9M132/20	9M132/20	12	.020" (0.508 mm) U/S	
9M132/30	9M132/30	12	.030" (0.762 mm) U/S	
9M132/40	9M132/40	12	.040" (1.016 mm) U/S	
9M132/60	9M132/60	12	.060" (1.524 mm) U/S	
9M133	9M133S	13	Thrust washer set - standard	
9M133/3	9M133/3	14	Thrust washer set - .003" (.076 mm) O/S	
9M135	10M135	15	Gear - crankshaft	
9M136	10M136	16	Key	
9M137	10M137	17	Washer - packing	
9M138	8M143	18	Camshaft	
9M139	10M139SH	19	Pin - oil pump driving	
9M140	10M140	20	Plate - camshaft locating	
9M141	FIX136	21	Screw - 1/4" UNF x 3/4"	
9M142	10M142	22	Washer - shakeproof - 1/4"	
9M143	10M143	23	Gear - camshaft	
9M144	10M144	24	Ring - tensioner	
9M145	9G227	25	Woodruff - 5/8"D x 5/32"	
9M146	10M138A	26	Washer - lock	
9M147	10M142	27	Nut	
9M148	10M148	28	Chain - timing	
9M149	10M149	29	Plate - engine mounting	
9M150	10M150	30	Gasket	
9M151	FIX138	31	Screw - plate to crankcase - 5/16" UNF	
9M152	FIX157	32	Washer - spring - 5/16"	
9M153	10M153	33	Screw - plate to bearing cap	
9M154	10M154	34	Plate - locking	
9M155	9M155SH	35	Flywheel	
9M156	9M156	36	Gear - ring starter	
9M157	10M157	37	Dowel	
9M158	FIX104	38	Screw - flywheel to crankcase - 3/8"	
9M159	10M159	39	Washer - lock	
9M160	10M160	40	Tappet - standard	
9M161	10M161	41	Pushrod	
9M162	10M162	42	Pulley - crankshaft	
9M163	FIX124	43	Nut - starting handle	
9M164	10M164	44	Washer - lock	
9M165	10M165SH	45	Housing - distributor	
9M166	9M166	-	'O' ring	
9M167	FIX136	46	Screw - 1/4" UNF x 3/4"	
9M168	10M142	47	Washer - shakeproof - 1/4"	
9M169	10M168	48	Spindle - distributor drive	